

Substrate Preparation

Substrate (for example)	Mastic asphalt screed acc. to DIN EN 13813 (AS)	Cement based screed acc. to DIN EN 13813 (CT)	Calciumsulfate- or calciumsulfate flowing screed acc. to DIN EN 13813(CA/CAF)	Dry screed
Primer (for example)	SCHÖNOX® SHP (not necessary if sufficient sanding)	SCHÖNOX® VD		
Self levelling compound (for example)	SCHÖNOX® HS 10 SCHÖNOX® HS 10 F SCHÖNOX® HS 50			SCHÖNOX® HS 10

Floor Covering Installation

Covering/ Collection	Adhesive	Tool/ trowel acc. TKB	Approx. consumption g/m ²	Remark
EGGER PRO AQUA+ Laminate flooring EGGER HOME AQUA+ Laminate flooring	SCHÖNOX® PROTECT Universal adhesive for highest loads	TKB B6 - B11	approx. 800 - 1000 g/m ²	Pay attention to adequate wetting of the back of the covering Drying time: approx. 24 hours
EGGER DESIGN-flooring Green TEC	SCHÖNOX® PARKETT 400 Universal wood adhesive for all kind of wood	TKB B3/ B6	approx. 800 - 900 g/m ²	
	SCHÖNOX® PARKETT 600 Waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/ B6	approx. 800 g/m ²	

Assembly recommendation for private bathrooms

SCHÖNOX® AB	SCHÖNOX® iFIX 2-component, rollable adhesive	roller	approx. 460 g/m ²	
SCHÖNOX® FUGENDICHTBAND				
EGGER DESIGN-flooring Green TEC	SCHÖNOX® PARKETT 400 Universal wood adhesive for all kind of wood	TKB B3/ B6	approx. 800 - 900 g/m ²	
	SCHÖNOX® PARKETT 600 Waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/ B6	approx. 800 g/m ²	

All adhesive fulfill EC1^{PLUS} acc. to GEV requirements, unless otherwise noted

Please follow the technical information of relevant SCHÖNOX product data sheets, the advices of the manufactures of floor covering and also according to the well-known guidelines and instructions. If in doubt please do some practical tests or call the SCHÖNOX Productservice under phone +02547/910-325. More detailed information, product data sheets or laying instructions are available under www.schoenox.com or www.egger.com